


Disassembly and Recycling Instructions

Diddy 2450


Tools Required:




Safety Glasses



Metric Allen
Wrenches



Hammer



Wrenches/Ratchet

1. Remove Casters from the base. Recycle Casters
2. Face the chair down and Hammer the control while pulling on the base to separate.
3. Separate the Cylinder from the base then recycle.
4. Face the shell down and use the allen wrench to remove and unscrew the arm. Recycle Arm
5. Use a wrench to remove the control and then recycle.
6. Discard the Shell.



Shell

Plywood/Polyurethane foam



Arms

Hot Rolled Flat Stock Steel



Control

Polypropylene, Steel



Gas Lift

Steel



Base

Cast Aluminum



Casters

Polypropylene, Nylon, ABS



= Recyclable Material Content